

MODEL 752A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT.COND.	NOTATIONS	
1A4	2.0	4100-2300	18	---	X2	---	225	CAP=G. Hold down S1 and Press S5	
1A6	2.0	6100-2504	12	---	X2	---	225	Pent. Sect. CAP = G Hold down S1 and Press S5	
1A6	2.0	6140-3502	25	---	X1	S5	125	Osc. Sect.	
1AB5	1.1	8160-2300	0	---	X2	S5	375		
1B5	2.0	6150-2000	10	---	X1	S5	350	Triode Sect.	
1B5	2.0	6100-4300	0	40	SH	S1	400	X Dual Diode	
1B7	1.4	7200-3405	4	---	X2	---	300	Pent. Sect. CAP = G Hold down S1 and Press S5	
1B7	1.4	7250-6403	17	---	X2	---	200	Osc. Sect. Hold down S1 and Press S5	
1C5	2.0	6100-2534	13	---	X2	---	250	Ampl. Sect. CAP = G Hold down S1 and Press S5	
1C6	2.0	6140-3520	28	---	X1	S5	150	Osc. Sect.	
1C7	2.0	7200-3465	13	---	X2	---	250	Pent. Sect. CAP = G Hold down S1 and Press S5	
1C7	2.0	7250-6430	28	---	X1	S5	150	Osc. Sect.	
1C8	1.1	4520-7608	40	---	X1	S5	175		
1D7	2.0	7200-3465	12	---	X2	---	225	Pent. Sect. CAP = G Hold down S1 and Press S5	
1D7	2.0	7250-6430	25	---	X1	S5	125	Osc. Sect.	
1D8	1.4	7250-3460	18	---	X2	---	275	Pent. Sect. Hold down S1 and Press S5	
1D8	1.4	7200-6000	0	---	X1	S5	350	Triode Sect. CAP = G	
1D8	1.4	7200-8000	0	0	SH	S1	400	Diode Sect.	
1E4	1.4	7250-3000	25	---	X2	S5	375		
1E5	2.0	7200-3400	15	---	X1	S5	400	CAP = G	
1E7	2.0	7250-6834	11	---	X2	S5	350	Pent. No. 1	
1E7	2.0	7240-3865	11	---	X2	S5	350	Pent. No. 2	
1F4	2.0	5130-2400	22	---	X2	S5	425		
1F5	2.0	7250-3400	22	---	X2	S5	425		
1F6	2.0	6100-2300	8	---	X2	---	200	Pent. Sect. CAP = G Hold down S1 and Press S5	
1F6	2.0	6100-5400	8	0	SH	S1	400	X Dual Diode	
1F7	2.0	7200-3600	8	---	X2	---	200	Pent. Sect. CAP = G Hold down S1 and Press S5	
1F7	2.0	7200-4530	8	0	SH	S1	400	X Dual Diode	
1G4	1.4	7250-3000	48	---	X2	S5	250		
1G5	2.0	7250-3040	16	---	X2	---	475	Hold down S1 and Press S5	
1G6	1.4	7254-6300	19	---	X2	S5	200	X Dual Triode	
1H4	2.0	7250-3000	40	---	X2	S5	275		
1J5	2.0	7250-3400	46	---	X2	S5	300		
1J6	2.0	7254-6300	23	---	X2	S5	300	X Dual Triode	
1LB6	1.4	8160-2437	Use this setting for Short Check only						
1LB6	1.4	8160-3574	22	---	X1	S5	300		
1N6	1.4	7250-3400	40	---	X2	S5	250	Pentode Sect.	
1N6	1.4	7200-6000	0	0	SH	S1	400	Diode Sect.	
1P5	1.4	7200-3400	12	---	X2	S5	250	CAP = G	
1R4	1.4	8100-4070	0	48	SH	S1	400		

MODEL 752 A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT. COND.	NOTATIONS
1SA6	1.4	7240-8630	0	---	X2	---	250	Hold down S1 and Press S5
1SB6	1.4	7280-3400	12	---	X1	S5	400	Pentode Sect.
1SB6	1.4	7280-5000	0	0	SH	S1	400	Diode Sect.
1T5	1.4	7250-3400	44	---	X2	S5	350	
2A4	2.5	7250-3000	#	93	SH	S6	650	Strikes at about 44
2A5	2.5	6140-2350	23	---	X2	S5	625	
2A6	2.5	6100-2050	11	---	X4	S5	175	Triode Sect. CAP = G
2A6	2.5	6100-4350	11	32	SH	S1	400	X Dual Diode
2A7	2.5	7100-2365	0	---	X2	S4	300	Pent. Sect. CAP = G
2A7	2.5	7150-4362	22	---	X1	S5	225	Osc. Sect.
2B4	2.5	5130-2040	#	93	SH	S6	650	Strikes at about 58
2B6	2.5	7140-2360	18	---	X2	S5	475	
2B22	6.3	7200-0080	0	30	SH	S3	650	Top Washer = P
2C4	2.5	7130-5040	#	93	SH	S6	650	Strikes at about 72
2C22	6.3	7200-0080	23	---	X4	S5	475	Far CAP = G
								Near CAP = P
2C26	6.3	7200-0080	13	---	X2	S5	550	Right CAP = P
								Left CAP = G
2C40	6.3	7200-0080	20	---	X4	S5	425	CAP = P. Ring = G
2E5	2.5	6150-4030	0	100	SH	S5	---	Eye Open
2E5	2.5	6150-4230	0	100	SH	S5	---	Eye Closed
2V3	2.5	7200-0000	0	78	SH	S6	650	CAP = P
2W3	2.5	8200-4000	0	0	SH	S3	400	
2Z2	2.5	4100-2000	0	0	SH	S3	400	
3A8	2.5	7200-3400	17	---	X2	S5	225	Pentode Sect. CAP = G
3A8	2.5	7250-6000	0	---	X1	S5	175	Triode Sect.
3A8	2.5	7200-8000	0	32	SH	S1	400	Diode Sect.
3B5	2.5	7250-3400	33	---	X2	S4	425	
3B7	2.5	1850-7000	27	---	X2	S5	475	Triode No. 1
3B7	2.5	8130-2000	27	---	X2	S5	475	Triode No. 2
3C6	2.5	1850-6000	10	---	X2	S4	350	Triode No. 1
3C6	2.5	8140-3000	10	---	X2	S4	350	Triode No. 2
5AX4	5.0	8200-6000	0	36	SH	S3	400	Plate No. 1
5AX4	5.0	8200-4000	0	27	SH	S3	400	Plate No. 2
5X3	5.0	4100-3000	0	34	SH	S3	400	Plate No. 1
5X3	5.0	4100-2000	0	20	SH	S3	400	Plate No. 2
6A4	6.3	5130-2400	28	---	X2	S5	625	
6AB5	6.3	6150-4030	0	100	SH	S5	---	Eye Open
6AB5	6.3	6150-4230	0	100	SH	S5	---	Eye Closed
6AB6	6.3	7250-3480	0	---	X2	S5	450	
6AC6	6.3	7250-3480	0	---	X2	S5	750	
6AD6	6.3	7240-3580	0	100	SH	S5	---	Eye 1 Open, Eye 2 Closed
6AD6	6.3	7230-4580	0	100	SH	S5	---	Eye 2 Open, Eye 1 Closed
6AE5	6.3	7250-3080	72	---	X2	S5	375	
6AE6	6.3	7250-4083	0	---	X2	S5	225	Triode No. 1
6AE6	6.3	7250-3084	0	---	X2	S5	250	Triode No. 2
6AE7	6.3	7260-3084	33	---	X2	S5	475	Triode No. 1
6AE7	6.3	7240-3056	33	---	X2	S5	475	Triode No. 2
6AF5	6.3	7250-3080	52	---	X2	S5	475	

MODEL 752A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT.COND.	NOTATIONS
6AH5	6.3	7260-4 $\frac{1}{2}$ 80	17	---	X10	S5	300	
6AJ7	6.3	7240-8653	15	---	X10	S5	375	
6AK7	6.3	7240-8651	12	---	X10	S5	475	
6AW7	6.3	7820-6010	10	---	X4	S5	175	Triode Sect.
6AW7	6.3	7800-3451	0	76	SH	S1	400	X Dual Diode
6AX6	6.3	7200-5384	0	58	SH	S3	650	X Dual Diode
6B5	6.3	6140-2350	0	---	X2	S5	525	
6B6	6.3	7200-3080	11	---	X4	S5	175	Triode Sect. CAP =
6B6	6.3	7200-5480	11	32	SH	S1	400	X Dual Diode
6B8	6.3	7200-3681	22	---	X2	S5	300	Pent. Sect. CAP = G
6B8	6.3	7200-5481	22	32	SH	S1	400	X Dual Diode
6C7	6.3	7100-2060	26	---	X2	S5	375	Triode Sect. CAP =
6C7	6.3	7100-5460	26	30	SH	S1	400	X Dual Diode
6C8	6.3	7205-3648	15	---	X2	S5	500	X Dual Triode. CAP =
6D5	6.3	7250-3080	57	---	X2	S5	625	
6D7	6.3	7100-2364	21	---	X2	S5	375	CAP = G
6D8	6.3	7200-3485	0	---	X2	S4	300	Pent. Sect. CAP = G
6D8	6.3	7250-6483	22	---	X1	S5	225	Osc. Sect.
6E6	6.3	7153-6240	51	---	X2	S5	425	X Dual Triode
6E7	6.3	7100-2364	17	---	X2	S5	500	CAP = G
6G5	6.3	6150-4030	0	100	SH	S5	---	Eye Open
6G5	6.3	6150-4230	0	100	SH	S5	---	Eye Closed
6H4	6.3	7200-4080	0	73	SH	S1	400	
6K5	6.3	7200-3080	15	---	X4	S5	225	CAP = G
6N5	6.3	6150-4030	0	100	SH	S5	---	Eye Open
6N5	6.3	6150-4230	0	100	SH	S5	---	Eye Closed
6N6	6.3	7250-3480	0	---	X2	S5	525	
6P7	6.3	2300-4586	18	---	X2	S5	350	Pent. Sect. CAP = G
6P7	6.3	2370-6084	35	---	X2	S5	150	Triode Sect.
6Q6	6.3	7200-3080	13	---	X2	S5	300	Triode Sect. CAP =
6Q6	6.3	7200-5480	13	30	SH	S1	400	X Dual Diode
6SZ7	6.3	7820-6031	15	---	X4	S5	175	Triode Sect.
6SZ7	6.3	7800-5431	0	30	SH	S1	400	X Dual Diode
6T5	6.3	6150-4030	0	100	SH	S5	---	Eye Open
6T5	6.3	6150-4230	0	100	SH	S5	---	Eye Closed
6T7	6.3	7200-3080	13	---	X2	S5	300	Triode Sect. CAP =
6T7	6.3	7200-5480	13	30	SH	S1	400	X Dual Diode
6U7	6.3	7200-3485	17	---	X2	S5	500	CAP = G
6V7	6.3	7200-3080	42	---	X2	S5	300	Triode Sect. CAP =
6V7	6.3	7200-5480	42	30	SH	S1	400	X Dual Diode
6W5	6.3	7200-5380	0	20	SH	S3	650	X Dual Diode
6Y7	6.3	7200-3485	21	---	X2	S5	375	CAP = G
6Y5	6.3	6100-5340	0	58	SH	S3	650	X Dual Diode
6Y7	6.3	7254-6380	13	---	X2	S5	300	X Dual Triode
6Z7	6.3	7254-6380	14	---	X2	S5	375	X Dual Triode
7AB7	6.3	7250-3140	10	---	X4	S5	250	
7AJ7	6.3	8160-2374	8	---	X4	S5	350	
7B5	6.3	8160-2370	17	---	X4	S5	375	
7B6	6.3	8130-2070	11	---	X4	S5	175	Triode Sect.
7B6	6.3	8100-6572	0	30	SH	S1	400	X Dual Diode

MODEL 752A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT.COND.	NOTATIONS
7B8	6.3	8160-2574	0	---	X2	S4	300	Pent. Sect.
7B8	6.3	8140-3576	22	---	X1	S5	225	Osc. Sect.
7C4	6.3	8100-4070	0	70	SH	S1	400	
7G8	6.3	8150-7362	11	---	X4	S5	325	Tetrode No. 1
7G8	6.3	8140-2367	11	---	X4	S5	325	Tetrode No. 2
7S7	6.3	8160-2574	16	---	X2	S5	475	Heptode Sect.
7S7	6.3	8140-3075	14	---	X2	S5	525	Triode Sect.
7T7	6.3	8160-2374	10	---	X4	S5	475	
10	7.5	4130-2000	44	---	X2	S5	375	
10Y	7.5	4130-2000	44	---	X2	S5	375	
12A	5.0	4130-2000	48	---	X2	S5	525	
12A5	12.6	7140-2350	38	---	X2	S5	550	
12A6	12.6	7250-3481	18	---	X4	S5	475	
12B8	12.6	7200-3410	18	---	X4	S5	275	Pent. Sect. CAP = G
12B8	12.6	7280-5060	7	---	X4	S5	300	Triode Sect.
12F5	12.6	7200-4080	12	---	X4	S5	225	CAP = G
12SW7	12.6	7820-6031	21	---	X2	S5	600	Triode Sect.
12SW7	12.6	7800-5436	0	30	SH	S1	400	X Dual Diode
12SX7	12.6	7841-5263	23	---	X4	S5	400	X Dual Triode
12SY7	12.6	7280-3465	10	---	X4	---	150	Ampl. Sect. Hold down S1 and Press S5
12SY7	12.6	7250-4068	22	---	X4	S5	625	Osc. Sect.
12Z3	12.6	4100-2030	0	35	SH	S3	650	
12Z5	6.3	6100-5040	0	30	SH	S3	650	Plate No. 1
12Z5	6.3	2100-3040	0	30	SH	S3	650	Plate No. 2
14A4	12.6	8160-2070	23	---	X4	S5	400	
14A5	12.6	8160-2370	18	---	X4	S5	475	
14E7	12.6	8160-2570	20	---	X4	S5	200	Pent. Sect.
14E7	12.6	8100-4372	0	30	SH	S1	400	X Dual Diode
14Z3	12.6	4100-2030	0	35	SH	S3	650	
15	2.0	5100-2340	0	---	X2	---	225	CAP = G. Hold down S1 and Press S5
19	2.0	6143-5200	23	---	X2	S5	300	X Dual Triode
RK20A	7.5	5130-0240	0	---	X2	S5	625	CAP = P
22	3.0	4100-2300	0	---	X1	S5	300	CAP = G
24A	2.5	5100-2340	25	---	X2	S5	300	CAP = G
VT25A	7.5	4130-2000	44	---	X2	S5	375	
25A7	25.0	7250-3486	32	---	X2	S5	550	Pent. Sect.
25A7	25.0	7200-6013	0	40	SH	S3	650	Rect. Sect.
25AC5	25.0	7250-3080	0	---	X2	S5	475	
25B5	25.0	6140-2350	0	---	X2	S5	625	
25B6	25.0	7250-3480	20	---	X10	S4	300	
25B8	25.0	7200-3410	18	---	X4	S5	275	Pent. Sect. CAP = G
25B8	25.0	7280-5060	7	---	X4	S5	300	Triode Sect.
25D8	25.0	7200-3410	18	---	X4	S5	300	Pent. Sect. CAP = G
25D8	25.0	7250-6010	12	---	X4	S5	175	Triode Sect.
25D8	25.0	7200-8010	12	53	SH	S1	400	Diode Sect.

MODEL 752A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT. COND.	NOTATIONS
25N6	25.0	7250-3480	0	---	X2	S5	625	
25T	6.3	4130-0000	0	---	X2	S5	275	CAP = P
25Y5	25.0	6100-5243	0	30	SH	S3	650	X Dual Diode
25Z3	25.0	6100-5243	0	30	SH	S3	650	X Dual Diode
25Z4	25.0	7200-5080	0	50	SH	S3	650	
25Z5	25.0	6100-5243	0	30	SH	S3	650	X Dual Diode
26	1.4	4130-2000	39	---	X2	S5	350	
27	2.5	5130-2040	41	---	X2	S5	300	
30	2.0	4130-2000	43	---	X2	S5	275	
31	2.0	4130-2000	41	---	X2	S5	275	
32L7	35.0	7250-3480	16	---	X10	S4	300	Pent. Sect.
32L7	35.0	7200-6013	0	45	SH	S3	650	Rect. Sect.
33	2.0	5130-2400	27	---	X2	S5	400	
RK33	6.3	7104-3526	35	---	X2	S5	425	X Dual Triode. CAP = G
34	2.0	4100-2300	16	---	X2	---	175	CAP = G. Hold down S1 and Press S5
35	2.5	5100-2340	20	---	X2	S5	300	CAP = G
35A5	35.0	8160-2370	0	---	X10	S4	300	
35Z4	35.0	7200-5080	0	50	SH	S3	650	
35Z6	35.0	7200-5384	0	50	SH	S3	650	X Dual Diode
36	6.3	5100-2340	31	---	X2	S5	325	CAP = G
37	6.3	5130-2040	42	---	X2	S5	275	
38	6.3	5100-2340	35	---	X2	S5	325	CAP = G
39/44	6.3	5100-2340	25	---	X2	S5	300	CAP = G
40	5.0	4130-2000	20	---	X1	S5	125	
40Z5	50.0	7200-5080	0	53	SH	S3	650	
41	6.3	6140-2350	17	---	X4	S5	375	
42	6.3	6140-2350	23	---	X2	S5	625	
43	25.0	6140-2350	18	---	X4	S5	350	
45Z3	50.0	7100-2040	0	44	SH	S3	650	
45Z5	50.0	7200-5080	0	53	SH	S3	650	
46	2.5	5130-2400	0	---	X2	S5	625	
47	2.5	5130-2400	0	---	X2	S5	625	
48	25.0	6140-2350	45	---	X2	S5	625	
49	2.0	5130-2400	49	---	X2	S5	350	
50	7.5	4130-2000	60	---	X2	S5	475	
50Y6	50.0	7200-5384	0	45	SH	S3	650	X Dual Diode
50Z7	50.0	7200-5384	0	45	SH	S3	650	X Dual Diode
51/51S	2.5	5100-2340	20	---	X2	S5	325	CAP = G
HD51	OFF	0000-5020	---	---	VR	S9	150 V.	(155V. Regulation = 2 vol (from 5 to 30 MA.
57A	6.3	6100-2354	21	---	X2	S5	375	CAP = G
58A/58AS	6.3	6100-2354	17	---	X2	S5	500	CAP = G
VT67	2.0	4130-2000	43	---	X2	S5	275	
HY65	6.3	7250-0408	0	---	X4	S5	425	CAP = P
HY69	6.3	5130-0240	0	---	X4	S5	475	CAP = P
70A7	75.0	7250-3480	80	---	X4	S5	475	Pent. Sect.
70A7	75.0	7200-1000	0	58	SH	---	650	Rect. Sect. Reverse Mate Hold down S7 and Press S

MODEL 752 *k*

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT.COND.	NOTATIONS
71A	5.0	4130-2000	69	---	X2	S5	525	
79	6.3	6103-5240	13	---	X2	S5	300	X Dual Triode. CAP = G
81	7.5	4100-2000	0	0	SH	S3	400	
82	2.5	4100-3200	0	55	SH	S3	650	X Dual Diode
85	6.3	6100-2050	42	---	X2	S5	300	Triode Sect. CAP = G
85	6.3	6100-4352	42	30	SH	S1	400	X Dual Diode
85AS	6.3	6100-2050	26	---	X2	S5	375	Triode Sect. CAP = G
85AS	6.3	6100-4352	26	30	SH	S1	400	X Dual Diode
99	3.0	4130-2000	20	---	X1	S5	250	
112A	5.0	4130-2000	48	---	X2	S5	525	
CK113	50.0	7250-3486	32	---	X2	S5	550	Pent. Sect.
CK113	50.0	7200-6013	0	40	SH	S3	650	Rect. Sect.
HY114	1.4	7200-0000	22	---	X2	S5	350	Right CAP = P. Left CAP = G
117Z4	117.0	7200-5080	0	50	SH	S3	650	
183	5.0	4130-2000	79	---	X2	S5	475	
244A	2.0	5130-2040	42	---	X2	S5	150	
257A	3.0	4100-2000	16	---	X1	S5	300	CAP = G
259A	2.0	5100-2340	19	---	X2	S5	250	CAP = G
264C	1.4	4130-2000	20	---	X1	S5	300	
271A	5.0	5130-2040	32	---	X4	S5	400	
283A	2.0	5100-2340	28	---	X2	S5	300	CAP = G
285A	2.0	5100-2340	31	---	X2	S5	300	CAP = G
310A	10.0	6100-2354	20	---	X2	S5	475	CAP = G
311A	10.0	5100-2340	31	---	X2	S5	700	CAP = G
482A	5.0	4130-2000	79	---	X2	S5	475	
482B	5.0	4130-2000	58	---	X2	S5	475	
483	5.0	4130-2000	79	---	X2	S5	475	
485	3.0	5130-2040	37	---	X2	S5	400	
CK505AX	0.6	3540-1200	17	---	X1	S5	100	
CK510AX	0.6	4710-2306	0	0	SH	S6	50	Sect. No. 1
CK510AX	0.6	4760-5301	0	0	SH	S6	50	Sect. No. 2
CK556AX	1.1	4230-1000	26	---	X2	S5	500	
CK568AX	1.1	4230-1000	38	---	X2	S5	200	
CK569AX	1.1	3540-1200	8	---	X1	S5	525	
CK571AX	1.1	3470-1200	57	---	X1	S5	100	
CK573AX	1.1	2430-1000	34	---	X2	S5	625	
CK574AX	0.6	3540-1200	15	---	X1	S5	100	
CK605CX	6.3	3470-1265	10	---	X4	S5	675	
CK606BX	6.3	2300-1040	0	80	SH	S1	400	
CK608CX	6.3	3450-1060	22	---	X10	S5	300	
CK619CX	6.3	2340-1050	7	---	X10	S5	250	
717A	6.3	7240-8631	8	---	X4	S5	475	
814	10.0	5130-0240	0	---	X2	S5	750	CAP = P. Fuse lamp will glow brightly
SD828A	6.3	4630-1520	22	---	X4	S5	300	
SD828E	6.3	4630-0512	12	---	X10	S5	325	TOP LEAD = P
834	7.5	4100-0000	0	---	X2	S5	525	Near CAP = G Far CAP = P

MODEL 752 A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT.COND.	NOTATIONS
SD917A	6.3	3420-1050	10	---	X4	S4	425	
SN944	6.3	4630-0512	12	---	X4	S5	375	Top Lead = P
SN946B	6.3	2300-1040	0	80	SH	S1	400	
SN947D	6.3	3610-5780	44	---	X10	S5	300	
SN949C	6.3	3670-1052	#	50	SH	S3	650	Strikes at about 78
SN953D	6.3	3610-5720	15	---	X10	S5	350	
SN954	6.3	4200-1030	0	0	SH	S3	650	
SN954B	6.3	3600-2050	0	0	SH	S3	650	
SN956B	1.1	1200-0000	0	---	X1	S3	400	Top Lead = P. Connect Fil. leads to Pins 1 and
SN957A	6.3	5340-1020	25	---	X4	S5	425	
SN972D	6.3	3610-5740	13	---	X4	S5	475	
SN973B	6.3	3610-5740	16	---	X4	S5	475	
SN976C	6.3	3610-5780	44	---	X10	S5	300	
SD993C	6.3	3610-8050	19	---	X10	S5	300	
SD995B	6.3	3610-5740	13	---	X4	S5	475	
FM1000	6.3	8120-4536	0	---	X2	S5	225	Grid No. 1
FM1000	6.3	8160-4532	0	---	X2	S5	275	Grid No. 2
1005	6.3	6800-3050	0	93	SH	S6	650	Plate No. 1
1005	6.3	6800-5030	0	93	SH	S6	650	Plate No. 2
SN1006	6.3	5340-1200	9	---	X4	S4	225	
CK1027	OFF	0000-4070	0	91	SH	S6	650	CAP = P
E1148	6.3	7200-0080	12	---	X4	S5	350	Upper CAP = P Lower CAP = G
1247	0.6	4500-0000	0	0	SH	S1	400	Top Lead = P
HY1269	12.6	5130-0240	0	---	X10	S5	275	CAP = P. Short on 1-2
1291	2.5	1860-7000	27	---	X2	S5	475	Triode No. 1
1291	2.5	8130-2000	27	---	X2	S5	475	Triode No. 2
1602	7.5	4130-2000	44	---	X2	S5	375	
1616	4.3	4100-0000	0	30	SH	S2	650	CAP = P
1625	12.6	7140-0360	28	---	X4	S5	600	CAP = P
1626	12.6	7250-3080	46	---	X2	S5	650	
1629	12.6	7250-4080	0	100	SH	S5	---	Eye Open
1629	12.6	7250-4380	0	100	SH	S5	---	Eye Closed
1641	5.0	4100-0000	0	28	SH	S3	650	Left CAP = P
1641	5.0	1400-0000	0	28	SH	S3	650	Right CAP = P
1650	6.3	6140-3070	24	---	X2	S5	600	
1654	1.4	1700-0000	0	67	SH	S6	650	CAP = P
5517	OFF	0000-4070	0	40	SH	S2	650	CAP = P
5591	6.3	4310-5620	10	---	X4	S5	675	
5603	6.3	2740-8623	42	---	X4	S5	625	
5608A	2.5	7153-6240	17	---	X2	S5	475	⌘ Dual Triode
5823	OFF	0000-1030	0	91	SH	S6	650	Place a 1 megohm $\frac{1}{2}$ watt resistor across pins 1 and 4 in Octal socket
5901	6.3	3610-5740	16	---	X4	S5	475	
7193	6.3	7200-0080	23	---	X4	S5	475	Far Cap = G Near Cap = P

MODEL 752A

Supplementary Tube Test Data for Obsolete Tube Types

TUBE TYPE	FIL.	SELECTORS	BIAS	SHUNT	MULT.	PRESS	MIN. MUT. COND.	NOTATIONS
8005	10.0	4130-0000	0	---	X4	S5	400	CAP = P
38142	7.5	4130-2000	37	---	X2	S5	625	
XXB	2.5	1850-6000	10	---	X2	S4	350	Triode No. 1
XXB	2.5	8140-3000	10	---	X2	S4	350	Triode No. 2
XXD	12.6	8154-6372	27	---	X4	S5	325	X Dual Triode
XXFM	6.3	8130-2040	11	---	X4	S5	150	Triode Sect.
XXFM	6.3	8100-5647	0	77	SH	S1	400	X Dual Diode
XXL	6.3	8160-2070	23	---	X4	S5	400	

FREE DOWNLOAD - NOT FOR RESALE

Original Scan Source - Unknown

**Publication Provided By
Steve's Antique Technology**

www.StevenJohnson.com

