

TURN SELECTOR TO SOCKET		TURN SELECTOR TO SOCKET		TURN SELECTOR TO SOCKET		TURN SELECTOR TO SOCKET	
TUBE	SOCKET	TUBE	SOCKET	TUBE	SOCKET	TUBE	SOCKET
00A	55	22	38	69	9	986	8
01A	55	24A	29	70	17	AD	18
01AA	55	25	35	71A	2	AF	8
KR1	5	25S	35	75	17	AG	8
1V	14	25S	35	75	12	GA	6
1A6	28	25S	35	G75	12	LA	6
1C6	28	25S	35	G75	12	PA	5
G2S	27	KR25	28	G75	12	PZ	6
2A3	27	25Z5	51	76	10	PZH	1
2A3H	27	26	25	77	7	WUND	13
2A5	28	27	24	78	8	WUND	13
2A6	39	KR28	5	79	9	2.5	
2A6	23	29	29	80	6		
2A7	29	30	34	81	5		
2B7	29	31	32	82	22		
2B7	23	32	33	83	40		
G4S	27	33	32	84	5		
5Z3	4	34	33	G84	18		
6A4	10	35	29	85	27		
6Z4	18	36	7	85	10		
6Y5	5	36X	9	85A	12		
6Z5	14	37	8	85A	8		
6A6	10	38	8	89	11		
6C6	9	39	9	89B	11		
6D6	9	41	10	90	24		
6A7	7	42	11	92	10		
6B7	7	43	50	95	28		
6B7	12	44	9	96	43		
6C7	8	45	26	98	5		
6C7	12	46	31	99	39		
6D7	8	47	28	NU99	38		
6E7	8	48	52	182A	3		
6F7	9	49	32	182B	3		
10	20	50	21	183	2		
12A	1	51	29	205D	54		
12A5	49	52	15	257	3		
12A7	48	53	30	295	28		
12A7	44	55	28	401	42		
12Z3	44	55	23	403	41		
12Z5	44	56	28	481	22		
14	47	57	29	482A	3		
15	35	57A	9	482B	3		
17	48	58	24	483	2		
18	49	58A	8	484A	42		
19	36	59	28	485	42		
20	37	59B	28	486	39		
KR20	24	64	12	842	21		
NX20	42	65	9	866	40		
KR22	10	67	10	985	5		
		68	10				

SPACE FOR ADDITIONAL TUBES

102/ 35 9  
P/S 35 17  
Tub  
net

\*\*866—Use jumper with clip from top cap to plate hole in any socket

APPARATUS DESIGN COMPANY  
Little Rock, Arkansas

Models B and C not equipped with combination 5-6-7 prong #12 and #17 sockets cannot test diodes of tubes as listed above. Proper sockets, resistors and instructions for making these tests are available in what we call KIT #1. \$1.50 net.

Models B and C not equipped with combination 5-6-7 prong #9 socket and large and small 7 prong #10 socket cannot test 12A5, 12Z5 and both plates of 25Z5. Proper sockets and instructions for making these tests are available in what we call KIT #2. \$1.15 net.

Combination of the two kits \$2.25 net. Cash with order or shipped COD.

2A7 type tube. If your model chart gives test selector 23, socket 15, connect the cathode terminal of socket 15 to the open terminal next to it and use this chart, reading selector 29, socket 15.

12A7 type tube. Models B and C equipped with the combination #10 socket but not having 12A7 listed on the chart can be slightly altered to test the 12A7. Transpose the yellow and black wires on socket #10. This simply puts the yellow wires on the terminal where the black were, and puts the black wires on the terminal where the yellow were. Follow the above chart for tests. If your Model B or C is not equipped with the combination #10 socket, use KIT #2.



**[www.StevenJohnson.com](http://www.StevenJohnson.com)**

**Antique Technolgy, Tube Radios and Test Equipment  
Vintage Schematics, and Publications**

**Steve's Antique Technology**